

# VALANCE INSTALLATION QUICK GUIDE

Your valance comes with adjustable magnetic valance clips and also safety straps for quick and easy valance attachment and multi-position valance adjustment capabilities. The clips have two plastic stop lip tabs on the top. These tabs will be aligned to and rest on the top front lip of the headrail when installing the valance.

## IMPORTANT SAFETY NOTE:

THERE ARE 2 VALANCE SAFETY STRAPS LOCATED INSIDE THE HEADRAIL AT EACH END. (ONLY 1 STRAP IN CENTER OF HEADRAIL FOR BLINDS UNDER 36" WIDE ). THE VALANCE SAFETY STRAPS ARE LOOPED AND SECURED TO THE METAL TILT ROD INSIDE THE HEADRAIL. EACH STRAP HAS A CLIP ATTACHED AT THE END.

## **DO NOT REMOVE THE VALANCE SAFETY STRAPS OR CLIPS.**


THE CLIP END OF THE STRAP MUST BE TWISTED INTO THE BACKSIDE VALANCE ROUTE. THIS STEP SHOULD BE PERFORMED AFTER THE VALANCE IS FIRST ALIGNED AND PRESSED TO THE HEADRAIL (after quick steps 3 & 4 below).

PLEASE REFER TO THE COMPLETE INSTALLATION INSTRUCTIONS INCLUDED WITH YOUR BLIND FOR DETAILED INSTRUCTIONS AND DIAGRAMS ON BLIND & VALANCE INSTALLATIONS.


## QUICK STEPS - INSTALLING THE VALANCE:



TWIST MAGNETIC CLIPS INTO VALANCE ROUTE UNTIL STRAIGHT



ALIGN & PRESS VALANCE GENTLY FORWARD UNTIL MAGNETS HOLD



PIVOT UP VALANCE & SECURE SAFETY STRAPS

- 1. TWIST** the magnetic clips into the backside valance routes until straight.
- 2. PROJECT** the magnetic clips outward to their widest projection (3 notches out).
- 3. ALIGN** the valance to the headrail using the magnetic clip stop lip tabs.
- 4. PRESS** the valance gently forward until the magnets adhere to the headrail.
- 5. SECURE** the safety straps by twisting into each end of valance routes.
- 6. ADJUST** projection by pressing valance forward (face flush or returns to wall).